

Quick Mover QM180

The Quick Mover QM180 can pick up goods from gates and can also pick up the Shelf Cart SC400. The Quick Mover is placed on top of the mobile robot and functions by a lifting mechanism integrated in the module. The provided smartphone allows users to manually control the robot and **adjust specialized work processes**, which forms efficient automation of internal transportation. The Quick Mover also reduces costs and increases productivity.

Key benefits

- Simple setup and installation (30 minutes)
- Smartphone included
- Flexible standard product
- Reliable and cost-efficient
- Possibility to personalize the module



The Quick Mover docking in to the Slim Gate SG155

WORKS WITH

SG155, Solid Gate
 WG155, Wheel Gate
 GP155, Gate picking
 CT155, Cobot Tower
 SC400, Shelf Cart



Technical specifications

Parameter	QM180, Quick Mover
Dimensions (LWH)	800 x 600 x 240 mm 31" x 24" x 9.4"
Application weight	30 kg 66"
Transport area	800 x 600 mm 31" x 24"
Centre distance between arms	140 mm 5.5"
Color	RAL 7011 & RAL 5011
Handling capacity	MiR100: 70 kg 154" MiR200: 170 kg 374" MiR250: 220 kg 485"